

Face Shield Building Instructions



The presented face shield is fully produced from sheet material by laser-cutting, with a material cost of around 1.50 euro per shield. It contains only 4 parts, resists thorough cleaning with alcohol or soap and has a total weight of only 50 gram.


We have demonstrated a production speed of 460 full face shields in 24 working hours, including post-processing, cleaning and packing the shields.

This design by Demonstrator Lab Amsterdam is available at www.github.com/DemonstratorLab/ContraCovid


Team: Mark Laagland
Martin Slaman
Abbas Abdolalipour
Davide Iannuzzi



The shield part:



Laser cutter: BRM4060
Tube: 1250 mm max 80 W CO₂




Cut the shield part from 0.2 mm APET foil by making use of a custom made template. The template holds the foil in place by the exhaust holes in the template. The foil is cut at 350 mm/s at 76 W.




A home-made manual foil dispenser feeds the foil from the backside of the machine.

The frame parts:



The headband is cut from 2 mm HDPE at 14 mm/s and 78.5W. The spacer part is cut from 3 mm HDPE at 8 mm/s and 78.5W.


Both use an initial cut-through of 200 ms at 16 W.



Use a filter (fine-mesh) in the exhaust while cutting HDPE. Since laser-cutting will release a lot of particles.




You can mount an unpowered PC fan in the exhaust for monitoring the filter, connect it to a voltmeter.



The voltmeter shows the speed of airflow. Clean the filter when the value is low.



Use an up-side-down mounted scrape for cutting the edges created by the laser-cut. The guidance wheels (bearings) are not applying force (except gravity), this avoids cutting into the material.




Feed the headband from right to left (50%) and then gently pull back to the right while scraping the edges. Rotate 180 degrees and repeat for the remaining 50%.



Remove scrape defects and flakes by pulling the headband through a blue flame (quickly and smoothly)

The elastic band:



The bands are cut from 1 mm thick silicone rubber with a speed of 45 mm/s a power at high speed of 72 W and a power at low speed (around the corners) of 28 W.



Remove the remaining carbon particles after cutting by a damp cloth, then soak the bands in a solution of 70% alcohol in water for 10 minutes. Dry well and package directly after.

Face shield assembly:

- 1) Clean hands thoroughly for 20 seconds with soap and water
- 2) Fold the headband as pictured, keep the smooth side inwards to the forehead
- 3) Connect the spacer part (two hooks) to the headband (two holes)
- 4) Connect the rubber band
- 5) Connect the shield to the spacer, bend the arrowheads of the headband to connect them to the shield.

